

How to Create a Standard 2 lb Loaf Pan Wrapper

- Cut your piece of paper to 12" x 8"
- Measure in $2\frac{1}{4}$ " from each long side and score down the length of the paper
- Measure in $2\frac{1}{4}$ " from each short side and score between the long lines to create the loaf pan bottom shape
- Take your scissors and cut four $2\frac{1}{4}$ " slits along the score lines from each short end to the loaf pan bottom (as shown by the black lines below) - fold along all score lines and wrap around the tin to check for a good fit
You may need to trim diagonally along the flap edges on the ends to adjust for a neat fit.
- Once you are happy with the fit, fold up the ends and adhere using a strong adhesive such as Sticky Strip - and finally decorate!



